


FF06-2P (Version 2.07) User Guide 2013



PLEASE NOTE: THIS PRODUCT IS NOT APPROVED FOR USE IN CHINA

All Rights Reserved (C) Copyright 2002-2011, Pushkablu Data Communications Ltd

Pushkablu Data Communications Ltd
100, Alexandra Road, Poole, Dorset, BH14 9EP, United Kingdom
Tel: +44 (0) 1202 606285
Tel from U.S.A. (Toll Free): 1 866 895 3130
Email: martin002@pushkablu.co.uk

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Pushkablu Data Communications Ltd

Disclaimer

Pushkablu Data Communications Ltd makes no representations or warranties with respect to the contents hereof and specially disclaims any implied warranties or merchantability or fitness for any particular purpose. Further, Pushkablu Data Communications Ltd reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Pushkablu Data Communications Ltd to notify any such person of such revision or changes.

Trademarks

The Trademarks of the other Corporations which may be used in this manual are hereby acknowledged.

Warning: This Product may contain chemicals Known to the State of California to cause Cancer, and/or Birth Defects or Other Reproductive harm

Specifications:

1 x Multitech MT5600SMI Internal V34 Globally approved Modem
(MT5600SMI Conformity: UL 60590-1 (UL No: E150299)
 EN60950:2000, EN55022:1994+A1:1995+A2:1997
 EN55024:1998, TBR21:1998, FCC Part 68)
[See Multitech Declaration of Conformity on Page 29 of this document](#)

1 x RJ45 Serial Input (9,600bps, 8, N, 1)
 6 x Serial ports (Speeds 9600bps, 115,200bps)
 2 x AC (C13) Input 10 Amps 100-240VAC 50-60Hz
 2 x AC (C14) Output 10 Amps 100-240VAC 50-60Hz
 1 x External Autosensing 100-250VAC Power Adapter 5VDC (2.6amps)
 1 x DC Input 5VDC (1Amp Max)

Dimensions: 435mm (W) x 44mm (H) x 350mm (D)
 1U Rackmount
Weight: 2.5Kgs (5.5lbs)
Enclosure: Aluminium
Humidity: 10-80% non condensing
Operating Temperature: -10 to 45° C

Conformity:

IEC 60950-1:2001
 UL: 60950-1 CISPR 22/A1:2004
 CISPR 24/A2:2002 FCC CFR47: Part 15: 2006

Please note: This product does not have Homologation approvals for the following countries: [Mainland China](#), [Morocco](#), [Peru](#), [Tunisia](#), and [Vietnam](#).
 Please contact Pushkablu Data Communications Ltd for homologation status.

CAUTIONS, PLEASE READ BEFORE INSTALLATION

- 1) THIS UNIT SHOULD ONLY BE INSTALLED BY A PROFESSIONAL INSTALLATIONS ENGINEER WHO IS FAMILIAR WITH COMMERCIAL ELECTRICAL APPLIANCES.**
- 2) THIS UNIT IS INTENDED FOR INDOOR USE ONLY**
- 3) DO NOT INSTALL NEAR WATER OR EXPOSE THE PUSHKABLUЕ UNIT TO MOISTURE OR EXTREME TEMPERATURES.**
- 4) DO NOT OPEN THE PUSHKABLUЕ CHASSIS FOR ANY REASON OR MODIFY ANY PART OF THIS UNIT WITHOUT PERMISSION FROM PUSHKABLUЕ DATA COMMUNICATIONS LTD.**
- 5) USE THIS PRODUCT ONLY WITH EQUIPMENT THAT HAS BEEN UL, CUL, CB Approved.**
- 6) TO REDUCE THE RISK OF FIRE, USE ONLY 26 AWG (.41mm) OR LARGER TELEPHONE WIRING**
- 7) NEVER INSTALL TELEPHONE WIRING DURING A LIGHTENING STORM**
- 8) NEVER TOUCH UNINSULATED TELEPHONE WIRES OR TERMINALS UNLESS THE TELEPHONE WIRE HAS BEEN DISCONNECTED FROM THE NETWORK INTERFACE**
- 9) DO NOT USE DEVICE IN THE VICINITY OF A GAS LEAK**
- 10) THIS PRODUCT MUST BE DISCONNECTED FROM THE TELEPHONE NETWORK PRIOR TO SERVICING**

Regulatory Compliance USA and Canada

FCC Part 15

This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Plug the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC rules. Operation of this device is subject to the following conditions:

(1) This device may not

cause harmful interference, and

(2) this device must accept any interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement Canadien sur le matériel brouilleur.

FCC Part 68 Telecom

1. This equipment complies with part 68 of the Federal Communications Commission Rules. On the outside surface of this equipment is a label that contains, among other information, the FCC registration number. This information must be provided to the telephone company.

2. The suitable USOC jack (Universal Service Order Code connecting arrangement) for this equipment is shown below. If applicable, the facility interface codes (FIC) and service order codes (SOC) are shown.

3. An FCC-compliant telephone cord and modular plug is provided with this equipment. This equipment is designed to be connected to the telephone network or premises wiring using a compatible modular jack that is Part 68 compliant. See installation instructions for details.

4. The ringer equivalence number (REN) is used to determine the number of devices that may be connected to the telephone line.

Excessive RENs on the telephone line may result in the device not ringing in response to an incoming call. In most, but not all, areas the sum of the RENs should not exceed 5.0. To be certain of the number of devices that may be connected to the line, as determined by the total RENs, contact the local telephone company.

5. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the telephone company will notify you as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

6. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications in order to maintain uninterrupted service.

7. If trouble is experienced with this equipment (the model of which is indicated below) please contact Multi-Tech Systems, Inc. at the address shown below for details of how to have repairs made. If the trouble is causing harm to the telephone network, the telephone company may request you remove the equipment from the network until the problem is resolved.

8. No repairs are to be made by you. Repairs are to be made only by Pushkablu Data Communications Ltd or its licensees. Unauthorized repairs void Registration and Warranty.

9. This equipment should not be used on party lines or coin lines.

10. If so required, this equipment is hearing-aid compatible.

Manufacturer: Pushkablu Data Communications Ltd

Trade Name: Pushkablu

Model Number: FF06-2P

Registration No: None

Ringer Equivalence No: 0.1B

Modular Jack (USOC): RJ1 1C or RJ1 1W (single line)

Canadian Limitations Notice

Notice: The ringer equivalence number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the ringer equivalence numbers of all the devices does not exceed 5.

Notice: The Industry Canada label identifies certificated equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Industry Canada label does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations. Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment or equipment malfunctions may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Compliance Directive 1999/5/EC


UK	Pushkablue Data Communications Ltd hereby declares that this FF06-2P is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
Bulgaria	Pushkablue Data Communications Ltd декларирам на своя отговорност, че далекосъобщително устройство FF06-2P съответства на съществени изисквания по 1999/5/EC.
Czech Republic	Pushkablue Data Communications Ltd tímto prohlašuje, že FF06-2P je ve shodě se základními požadavky a s dalšími příslušnými ustanoveními Nařízení 1999/5/ES.
Denmark	Undertegnede Pushkablue Data Communications Ltd erklærer herved, at følgende udstyr FF06-2P overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
Netherlands	Hierbij verklaart Pushkablue Data Communications Ltd dat het toestel FF06-2P in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG. Bij deze verklaart Pushkablue Data Communications Ltd dat deze FF06-2P voldoet aan de essentiële eisen en aan de overige relevante bepalingen van Richtlijn 1999/5/EC.
Estonia	Käesolevaga kinnitab Pushkablue Data Communications Ltd seadme FF06-2P vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.
Finland	Pushkablue Data Communications Ltd vakuuttaa täten että FF06-2P tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.
France	Par la présente, Pushkablue Data Communications Ltd déclare que l'appareil FF06-2P est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE. Par la présente, Pushkablue Data Communications Ltd déclare que ce FF06-2P est conforme aux exigences essentielles et aux autres dispositions de la directive 1999/5/CE qui lui sont applicables.
Germany	Hiermit erklärt Pushkablue Data Communications Ltd, dass sich dieser FF06-2P in Übereinstimmung mit den grundlegenden Anforderungen und den anderen relevanten Vorschriften der Richtlinie 1999/5/EG befindet. Hiermit erklärt Pushkablue Data Communications Ltd die Übereinstimmung des Gerätes [Type des Gerätes] mit den grundlegenden Anforderungen und den anderen relevanten Festlegungen der Richtlinie 1999/5/EG.
Greece	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Pushkablue Data Communications Ltd ΔΗΛΩΝΕΙ ΟΤΙ FF06-2P ΣΥΜΜΟΡΦΟΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
Hungary	Pushkablue Data Communications Ltd ezennel kijelenti, hogy ez a FF06-2P termék megfelel az alapvető követelményeknek és az 1999/5/EC irányelv más vonatkozó rendelkezéseinek.
Iceland	Pushkablue Data Communications Ltd lýsir her með yfir að thessi bunadur, FF06-2P, uppfyllir allar grunnkröfur, sem gerdar eru í R&TTE tilskipun ESB nr 1999/5/EC
Italy	Con la presente Pushkablue Data Communications Ltd dichiara che questo FF06-2P è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
Latvia	Ar šo Pushkablue Data Communications Ltd deklarē, ka FF06-2P atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
Lithuania	Pushkablue Data Communications Ltd deklaruoja, kad irenginys FF06-2P tenkina 1999/5/EB Direktyvos esminius reikalavimus ir kitas sios direktyvos nuostatas
Malta	Hawnhekk, Pushkablue Data Communications Ltd , jiddikjara li dan FF06-2P jikkonforma mal-htigijiet essenzjali u ma provvedimenti oħrajn rilevanti li hemm fid-Direttiva 1999/5/EC.
Poland	Pushkablue Data Communications Ltd, deklarujemy z pełną odpowiedzialnością, że wyrób FF06-2P spełnia podstawowe wymagania i odpowiada warunkom zawartym w dyrektywie 1999/5/EC.
Portugal	Pushkablue Data Communications Ltd declara que este FF06-2P está conforme com os requisitos essenciais e outras proviões da Directiva 1999/5/CE.
Romania	Pushkablue Data Communications Ltd declară că aparatul FF06-2P este în conformitate cu cerințele esențiale și cu alte prevederi relevante ale otărârii Guvernului nr. 88/2003 (Directivei 1999/5/EC).
Slovakia	Pushkablue Data Communications Ltd týmto vyhlasuje, že tento FF06-2P vyhovuje technickým požiadavkám a ďalším ustanoveniam smernice 1999/5/ES, ktoré sa na tento výrobok vzťahujú.
Slovenia	S tem dokumentom Pushkablue Data Communications Ltd, izjavlja, da je ta FF06-2P v skladu z bistvenimi zahtevami in z drugimi ustreznimi določili Direktive 1999/5/EC.
Spain	Por medio de la presente Pushkablue Data Communications Ltd declara que el FF06-2P cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
Sweden	Härmed intygar Pushkablue Data Communications Ltd att denna FF06-2P står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Contents

FF06-2P Hardware Overview.....	Page 7
FF06-2P Hardware Installation.....	Page 8
FF06-2P Basic Operation.....	Page 9
Logging on	Page 9
Connecting to a Console Port	Page 9
To Disconnect from a Console Port	Page 9
FF06-2P Remote Power Function.....	Page 10
Power OFF Function	Page 10
Power ON Function	Page 10
Power Reboot Function	Page 10
Rommon Reboot Function (For Cisco Appliances)	Page 10
Group Reboot Function	Page 10
FF06-2P Configuration.....	Page 11-16
Configuration Using Abbreviated Commands.....	Page 11
Changing Admin 1 and Admin 2 Names & Passwords	Page 12
Add, Change & Delete Users	Page 13
Changing Prompt Name	Page 14
Changing Console Port & Power Port Names	Page 14
Split Administrator Gift Commands.....	Page 14
Other Configurations.....	Page 15
Adding, Removing Banner	Page 15
Changing Disconnect Character	Page 15
Turning PB Flow Control ON and OFF	Page 15
Set the number of dial rings (1-9)	Page 15
Set the Inactivity Timeout for Inactive data	Page 15
Turn login Prompt Display ON and OFF	Page 15
Configuration Using Menus.....	Page 16
FastFix Set Up Options.....	Page 16
Send Break Signal (For Cisco Appliances)	Page 16
Set Port Names	Page 17
Set System Time & Date	Page 17
Set Comm Port Speeds	Page 18
Set Security Keys	Page 19
Set Banner	Page 20
Other Main Menu Features	Page 20
Changing Admin 1 Name and Passwords.....	Page 21
Pushkablu Secure Administrator Software	Page 22

Set Comms Options.....		Page 23-24
Set Inactivity Timeout	Page 23	
Set Disconnect Character	Page 23	
Set PB Flow Control	Page 24	
Set login Prompt Display	Page 24	
Set dialing Type	Page 24	
Line Modulation Speeds	Page 24	
Set Number of Dial Rings	Page 24	
Pushkablu Manage Users.....		Page 25
Add User	Page 25	
Delete User	Page 25	
Delete All Users	Page 25	
Show user Configuration	Page 26	
Dial Out and Answer Call.....		Page 26-27
How to make a dial out call (Via TERM Port)	Page 26	
How to Disconnect a Call	Page 27	
How to Answer a Call	Page 27	
RJ45 Serial Port Pin Outs & Standard Cable Specifications.....		Page 28-29
Pushkablu Factory Default Reset.....		Page 29
Spare 10 Amp Fuse.....		Page 29
Multitech Internal V34 Globally Approved Modem.....		Page 30

Hardware Overview



- 1- Screw Insert for DC Bracket
- 2- 5V DC Connector 2.1mm (1Amp)
- 3- Modem Connector (RJ11)
- 4- Factory Reset Button (Behind Panel)
- 5- TERM (RS232) Port, (9,600bps, 8, None, 1)
- 6- Console Ports 1 to 3 (9,600bps to 115,200bps)

- 7- Console Ports 4 to 6 (9,600bps to 115,200bps)
- 8- AC Input A (110-250VAC, 50-60Hz, 10Amps Max Load)
- 9- AC Output A1 (110-250VAC, 50-60Hz, 10Amps Max Load)
- 10- AC Output B1 (110-250VAC, 50-60Hz, 10Amps Max Load)
- 11- AC Input B (110-250VAC, 50-60Hz, 10Amps Max Load)

Accessories

Included with the FF06-2P:

- 1 x Globtek AC (100-240V) to DC (5V 2.6Amps) Power Adapter.
- 6 x Red Straight Cat 5 UTP Cables (Straight Through, Patch leads) 2 mtrs (6ft)
- 1 x RJ45 to 9Way D Female Adapter (Connects PC Comm Ports to TERM Port, using straight RJ45 cable)
- 2 x IEC C13 to C14 Power Cord 2 mtrs (6ft)
- 1 x RJ11 Modem Cable 3 mtrs (9ft), 1 x RJ11 Modem Cable 5 mtrs (15ft)
- 1 x DC Connector S Bracket & Screw
- 1 x CD with User Guides & Software

If any of the above items are missing or damaged, or you have any support questions, please contact Pushkablu Data Communications Ltd.

email: pushkablu001@gmail.com

Telephone From USA (Toll Free) 1 866 895 3130


Telephone From UK: 01202 717116

Telephone From Rest of World: + 44 1202 717116

Office Hours: 9:00am UK GMT to 5:30pm (USA Eastern time)

Hardware Installation

Installation of the FF06-2P is very simple. We have created a step by step graphic below for your convenience, but there is no specific order required when connecting the cables and devices.



When you have connected the External Power Adapter to the FF06-2P and Power Source (100V to 250V 50-60Hz), you should see the TERM LED and AA LED, illuminate after 8 to 10 seconds later.

The FF06-2P is ready to receive calls.

When a call comes in, you should see the AA LED Flicker twice (If Dial Rings Default is set to 2 Rings).

After approximately 20 seconds, if the modem synchronization is successful, you will see the TX and RX LEDs illuminate.

If after the AA LED Flickers and then after approximately 20 seconds, it resets itself to constantly on, it means that Modems have not been able to negotiate a speed. This is normally due to a bad PSTN Line condition.

A solution for this is to get the calling modem to negotiate its speed at a lower level.

The AT Command to do this is: `AT+MS=V22B<CR>`

If you know a call has been instigated, but the AA LED does not Flicker, this could mean:

- 1) A Faulty Line
- 2) The Wrong Number is being called.
- 3) The Supplied Modem Cable has a fault

From experience, it is very rarely the PushkaBlue device.

A Solution is to attach a telephone to the Line, using the modem cable and get the calling operator to ring the number again.

FF06-2P Basic Operations

This section describes the basic operational features and functionality of the FF06-2P.

Logging On

If you are logging on via the TERM Port, you need the Pushkablu RJ45 to 9 Way d Adapter and a Straight RJ45 to RJ45 Cable (Patch lead).
Set the Terminal Emulation to: 9,600bps, 8, None, 1 (Please Note: <CR> = Enter in this document)

Hit <CR> to get the Login: prompt

The Factory Default Administrator login details are:

Administrator name: SysAdmin001

Administrator 1st Password: PushkaBlue

Administrator 2nd Password: DoNotKnow

(All of the above entries are case sensitive)

FF06-2P Main Menu

Previous User Login : <no one>

(1) - Console
(2) - Console
(3) - Console
(4) - Console
(5) - Console
(6) - Console
(A1) - Power Control Module
(B1) - Power Control Module
(G) - Group Reboot
(I) - Information
(C) - Input A/B Current Status
(L) - Logout
(V) - View Log File
(D) - Dial Out
(N) - aNswer Call
(F) - FastFix Setup Options
(M) - Manage Users
Ok :

The FF06-2P is ready to operate in its factory default state. So if you just wish to connect to console ports or invoke a Power change, this section will provide the information for basic operation.

Connecting to a console port

There are 6 x Console Ports on the FF06-2P.

From the Main menu choose the number of the console port (1 to 6) to connect, then press <CR>

Example, if you wish to connect to Console port 1, type: 1<CR>.

Hit <CR> again and you should see the network appliance login prompt.

To Disconnect from the console port,
(the factory default disconnect character is CTRL+X)

Hold the CTRL key down and press the letter X 3 times quickly. If successful, you should now be back at the FF06-2P Main Menu screen.

REMOTE POWER FUNCTIONS

Power OFF Function

If you wish to turn the power off to a network appliance that is connected to power outlet A1 or B1, from the Main Menu, type: A1<CR> or B1<CR>

A New Menu will appear:

Power - Status(S), On(N), Off(F), Reboot(R), Exit(X,<CR>) :Type: F<CR> A New question will appear:

How Long 1 - 168 hours :

Choose how many hours you would like the network appliance to be off. (1 to 168 Hours).

Example, if you want the network appliance to be turned off for 24 Hours type: 24<CR>

Power On Function

If you wish to turn the power back on to a network appliance, from the Main Menu, type: A1<CR> or B1<CR>

A New Menu will appear:

Power - Status(S), On(N), Off(F), Reboot(R), Exit(X,<CR>) :Type: N<CR>

This will turn on the P1 Outlet and return you to the Main menu.

Power Reboot Function

If you wish to invoke a power reboot function of network appliance that is connected to power outlets A1 or B1

from the Main Menu, type: A1<CR> or B1<CR>

A New Menu will appear:

Power - Status(S), On(N), Off(F), Reboot(R), Exit(X,<CR>) :Type: R<CR> A New question will appear:

Reboot (y/n)? Type: Y<CR>

You will now see a count down from 10 to 1 while the P1 Outlet is Off. Power is restored after 10 seconds and will take you back to the Main Menu.

Rommon Reboot Function (For Cisco Network Appliances)

If you wish to invoke a Rommon reboot function of a Cisco network appliance that is connected to power outlets A1 or B1 (Or both),

1) Follow the steps **Power Reboot function** ([above](#))

2) When you are taken back to the Main Menu, type:

F<CR> for FastFix Setup Options, then choose (B) – [Send Break](#)

3) You will be asked, which port.

4) Choose the Console Port (1 to 6) that the Cisco Network Appliance console port is connected to, you will then be returned to the Main Menu.

If you now choose that console port, you should see that the Cisco Network Appliance is in Rommon Mode.

Please note: You have approximately 60 seconds from the Power being re applied to send the break to the console port

GROUP REBOOT Function

If you wish to reboot both A1 and B1 Outlets at the same time

At The Main menu type: G<CR>

You will then be prompted with:

Enter Ports to Reboot from A1 B1 A (All) (<CR> alone to end):

Type: A<CR>

This will then invoke a Power Reboot on both Outlets A1 & B1 and you will then be returned to the Main Menu.

FF06-2P Configuration

There are two ways you can configure an FF06-2P.

- 1) Using Abbreviated Commands at the Main Menu (**Not** sub Menus)
- 2) Using the Menus and Sub menus. ([Page 16](#))

Configuration Using Abbreviated Commands

Please Note: You can **ONLY** enter abbreviated commands at the Main Menu.

FF06-2P Main Menu

```
Previous User Login : <no one>
(1) - Console
(2) - Console
(3) - Console
(4) - Console
(5) - Console
(6) - Console
(A1) - Power Control Module
(B1) - Power Control Module
(G) - Group Reboot
(I) - Information
(C) - Input A/B Current Status
(L) - Logout
(V) - View Log File
(D) - Dial Out
(N) - aNswer Call
(F) - FastFix Setup Options
(M) - Manage Users
Ok :<Enter your command lines here>
```

- 1) Abbreviated Commands can **ONLY** be entered at the Main Menu prompt.
- 2) The Abbreviated Commands field is not case sensitive, but the values may be (example: User names and Passwords)
- 3) If the Abbreviated command is entered incorrectly, it is ignored.
- 4) You can create a text file, using an application such as Notepad, for downloading the commands.
Please Note: The download of a text file must be done over a **Dial up connection**, **NOT** the terminal ports, as the TERM Port Does **NOT** have flow control and configurations would be lost.
- 5) Abbreviated Command configurations are **ONLY** available to Admin 1 and Admin 2. Some abbreviated commands are **NOT** available to Admin 2.

On the next page, a list of abbreviated commands and their functions.

Changing Admin 1 and 2 Names and Passwords

The FF06-2P has two Administrators. This enables network operations organizations or departments to share the same Out of Band management device on the same telephone line, but have no access to each other's console ports or power ports. It in effect creates two virtual out of Band Management devices in one, using only one telephone line. The factory default settings are:

Admin 1

Default Admin 1 name: [SysAdmin001](#)

Default Admin 1 Password 1: [PushkaBlue](#)

Default Admin 1 Password 2: [DoNotKnow](#)

(All of the above are case sensitive)

Admin 1 from factory default has access to [ALL](#) Console Ports & Power Ports

Admin 2

Default Admin 1 name: [SysAdmin002](#)

Default Admin 1 Password 1: [PushkaBlue](#)

Default Admin 1 Password 2: [DoNotKnow](#)

(All of the above are case sensitive)

Admin 2 from factory default has **NO** access to Console Ports & Power Ports

Below are the Admin 1 and Admin 2 Names and Password change commands (Please Note: **<CR>**=Enter)

Abbreviated Command	Admin 1	Admin 2	Parameters/Values	Description
AN=	✓	✓	1-16 Characters (No Spaces) Case Sensitive	Enables you to change the Admin 1 name (Default: SysAdmin001) Example: AN=NewAdmin1Name<CR> SysAdmin001 has now been changed to: NewAdmin1Name
AP1=	✓	✓	Minimum 8, Maximum 16 Characters, Case sensitive	Enables you to change the Admin 1 Password 1 (Default: PushkaBlue) Example: AP1=NewPassword1<CR> PushkaBlue has now been changed to: NewPassword1
AP2=	✓	✓	Minimum 8, Maximum 16 Characters, Case sensitive	Enables you to change the Admin 1 Password 2 (Default: DoNotKnow) Example: AP2=NewPassword2<CR> DoNotKnow has now been changed to: NewPassword2
AP=	✓	✓	Minimum 8, Maximum 16 Characters, Case sensitive	Enables you to change the Admin 1 Password 1, Disable Password 2 (Default: PushkaBlue) Example: AP=NewPassword1<CR> PushkaBlue has now been changed to: NewPassword1 & has disabled Password 2
A2N=	✓	✗	1-16 Characters (No Spaces) Case Sensitive	Enables you to change the Admin 2 name (Default: SysAdmin002) Example: A2N=NewAdmin2Name<CR> SysAdmin002 has now been changed to: NewAdmin2Name Please note: Admin 1 can ONLY do this once at factory default status
A2P1=	✓	✗	Minimum 8, Maximum 16 Characters, Case sensitive	Enables you to change the Admin 2 Password 1 (Default: PushkaBlue) Example: A2P1=NewAdmin2Password1<CR> PushkaBlue has now been changed to: NewAdmin2Password1 Please note: Admin 1 can ONLY do this once at factory default status
A2P2=	✓	✗	Minimum 8, Maximum 16 Characters, Case sensitive	Enables you to change the Admin 2, Password 2 (Default: DoNotKnow) Example: A2P2=NewAdmin2Password2<CR> DoNotKnow has now been changed to: NewAdmin2Password2 Please note: Admin 1 can ONLY do this once at factory default status
A2P=	✓	✗	Minimum 8, Maximum 16 Characters, Case sensitive	Enables you to change the Admin 2 Password 1, Disable Password 2 (Default: PushkaBlue) Example: A2P=NewAdmin2Password 1<CR> PushkaBlue has now been changed to: NewAdmin2Password1 & Has disabled Admin 2 Password 2 Please note: Admin 1 can ONLY do this once at factory default status

Add, Change & Delete Users

Each Administrator (Admin 1 and Admin 2) can add up to 10 User Accounts to each. User Accounts do **NOT** have configuration rights.

This section shows you how to: Add, Change & Delete user names, Passwords and Port Assignments.

Each Administrator can have up to 10 User Accounts (U1 to U10), Users do NOT have configuration rights

The Abbreviated Commands below show how to set up users and their parameters.

(Please note: <CR> = Enter)

Abbreviated Command	Admin 1	Admin 2	Parameters/Values	Description
UnN=	✓	✓	1-16 Characters (No Spaces) Case Sensitive	Enables you to Add or Change Username n where n value is 1 to 10 (Users 1 to 10) Example: U7N= FirewallOps01<CR> FirewallOps01 User name has been created in slot 7
UnP1=	✓	✓	Minimum 8, Maximum 16 Characters, Case sensitive	Enables you to Add or Change User n Password 1 where n value is 1 to 10 (Users 1 to 10) Example: U7P1= FireOpsPassword 1<CR> FirewallOps01 1 st Password is now: FireOpsPassword1
UnP2=	✓	✓	Minimum 8, Maximum 16 Characters, Case sensitive	Enables you to Add or Change User n Password 2 where n value is 1 to 10 (Users 1 to 10) Example: U7P2= FireOpsPassword 2<CR> FirewallOps01 2 nd Password is now: FireOpsPassword2
UnCP=	✓	✓	1;2;3;4;5;6	Enables you to Assign Console Ports 1 to 6 to User n where n value is 1 to 10 (Users 1 to 10) Please note: Each port number should be separated by a semi-colon (;) Example: U7CP=1;2;4;5<CR> User 7 (FirewallOps01) has console Port access to Ports: 1 ,2,4 & 5
UnPP=	✓	✓	A1 & B1	Enables you to Assign Power Port A1 & B1 to User n where n value is 1 to 10 (Users 1 to 10), Please note: Each port number should be separated by a semi-colon (;) Example: U7PP=A1<CR> User 7 (FirewallOps01) has Power Port access to:A1
UnDB=	✓	✓	Telephone number (16 digits)	Add or Change a Dial back Security telephone number including commas (,) where n value is 1 to 10 (Users 1 to 10) example: U7DB=9,1234567890 User 7 (FirewallOps01) dial back number is: 9,1234567890
UnDEL	✓	✓	1-10	Enables you to Delete Username n where n value is 1 to 10 (Users 1 to 10) Example: U7DEL<CR> User 7 (FirewallOps01) is now Deleted
DELALL	✓	✓	<CR>	Deletes ALL users in database (UPPER CASE) Example: DELALL<CR> ALL Users are now DELETED

You can add any parameter to any user account at anytime.

However, if you change the Console port or Power Port assignments to an existing User account, you have to re type ALL of the port numbers, because the system overwrites the current port assignment status of that User.

If you are assigning more than one port Console Port or Power Port to a User, each port number must be separated by a semi-colon (;).

Example User setup configuration for User 1:

U1N=FirewallOps02<CR>

U1P1=FireOpsPassword1<CR>

U1P2= FireOpsPassword2<CR>

U1DB=9,3314569001<CR>

U1CP=1;2;3<CR>

U1PP=A1<CR>

Changing Prompt Name

(Please note: <CR> = Enter)

Abbreviated Command	Admin 1	Admin 2	Parameters/Values	Description
PR=	✓	✗	1-32 Characters (including spaces)	Changes the Pushkablu Prompt name (Default: OK) Example: pr=Pushkablu-New York Prompt name would now show: Pushkablu-New York:

Changing Console Port and Power Port Names

Abbreviated Command	Admin 1	Admin 2	Parameters/Values	Description
CnN=	✓	✓	1 to 32 Characters (including Spaces)	Changes Console Port n Name (n = 1 to 6) Where n is the Console port number: Example: C1N=Cisco 2610-01 Console Port 1 name would now show: Cisco 2610-01
PnnN=	✓	✓	1 to 32 Characters (including Spaces)	Changes Power Port nn Name (nn =A1 or B1) Where nn is the Power port number: Example: PA1N=Cisco 2610-01 Power Power Port A1 name would now show: Cisco 2610-01 Power

Split Administrator Gift Commands

The Split Administrator function allows 2 separate departments of organizations share the same Out of Band device and telephone line, but each department cannot control or gain access to each other's console or power ports.

ACP=	✓	✓	1;2;3;4;5;6	Allocates Console Ports to other Administrator (Default: Not Active, until invoked by Admin 1) Example: If logged in as Admin 1: acp=4;5;6<CR> Console Port s 4,5 & 6, is now Gifted to Administrator 2
APP=	✓	✓	A1 & B1	Allocates Power Ports to other Administrator (Default: Not Active, until invoked by Admin 1) Example: If logged in as Admin 1: app=B1<CR> Power Port B1, is now Gifted to Administrator 2

Admin 1 has to [Gift](#) console and power ports to Admin 2. Once this has been instigated, Admin 1 loses control and access to these ports.

Admin 2 can however, [Gift](#) console and power ports back to Admin 1 also. The abbreviated commands are the same for each Administrator.

From a factory default status, Admin 1 can also change the default Admin 2 name (default: [SysAdmin002](#)) and Passwords (Default: [Pushkablu](#), [DoNotKnow](#)). But This Can **ONLY** be done **ONCE**.

If logged in as Admin 2, you can change the Admin 2 Name and Passwords independently from Admin1.

The commands to [Gift](#) console ports and Power ports are the same for both Admin 1 and Admin 2, they are:

To Gift Console Ports, type: acp=**n**<CR>
(**n** = Console port Number)

If you are Gifting more than one console port, place a semi-colon (;) between the numbers, example: acp=1;2;3<CR>

To Gift Power Ports, type: app=**nn**<CR>
(**nn** = Power Port Number A1 or B1)

Please Note: If you are Gifting more than one Power Port, place a semi-colon (;) between the numbers, example: app=A1;B1<CR>

Once this has been done, hit<CR> 3 times quickly to refresh the Main Menu, you should see the console and Power ports [Gifted](#) have gone from the Main Menu.

Other Configuration commands

- 1) Adding & Changing Login Banner
- 2) Changing Disconnect character
- 3) Turning PB Flow Control on or Off
- 4) Set the Number of Dial rings on Auto Answer
- 5) Set the Inactivity Timeout for Inactive data
- 6) Turn Login prompt Display on or off

(Please note: <CR> = Enter)

Abbreviated Command	Admin 1	Admin 2	Parameters/Values	Description
BN=	✓	✗	254 Characters (including spaces) BN=<CR>Disables banner	Adds a Security Banner at the Login Prompt. Use ln as the new line command. When finished with banner text press <CR> Please note: word wrap must be disabled if the banner text enters a new line Example: This is a secure site lnUnauthorized attempts will be prosecuted.<CR> This would read at the Login: This is a secure site Unauthorized attempts will be prosecuted To remove Banner type: BN=<CR>
DC=	✓	✗	Any Single Character	Change the Disconnect Character (Example Semi Colon (;) (Default: CTRL+XXX) Example: DC=D<CR> Disconnect character is now D (Pressed 3 times quickly to return to the Main Menu.
PBFC=	✓	✗	On or Off	Turns PB Flow Control on or Off (Example PBFC=On) (Default: On) Example: PBFC=off<CR> PB Flow Control is turned OFF Example: PBFC=On<CR> PB Flow Control is turned ON
DR=	✓	✗	1-9	Sets the number of dial rings before the FF06-2P answers the call (Default: 2) Example: DR=6<CR> The Pushkablue unit will answer on 6 rings
IT=	✓	✗	1-99	Changes the Inactivity time out parameter from 1-99 minutes (0=Never) (Default: 5) Example: IT=20<CR> The Pushkablue unit will disconnect the call or Terminal session when data inactivity is more than 20 minutes.
LPD=	✓	✗	On/Off	Changes the Login Display prompt On or Off (Default: On) Example: LPD=Off<CR> This removes the word LOGIN: when the modems synchronize Example: LPD=On<CR> This enables the word LOGIN: to appear when the modems Synchronize

FF06-2P Configuration Using Menus

(F) - FastFix Set Up Options

This section covers the (F)-FastFix Setup Options. To access the Pushkablu setup options:

From the Main Menu type: F<CR>

FF06-2P main Menu

```
Previous User Login : <no one>
(1) - Console
(2) - Console
(3) - Console
(4) - Console
(5) - Console
(6) - Console
(A1) - Power Control Module
(B1) - Power Control Module
(G) - Group Reboot
(I) - Information
(C) - Input A/B Current Status
(L) - Logout
(V) - View Log File
(D) - Dial Out
(N) - aNswer Call
(F) - FastFix Setup Options
(M) - Manage Users
Ok :
```

We will explain each option from the top down.

(B) - Send Break Signal (For Cisco Appliances)

The Send Break Signal function is designed to send a break sequence **ONLY** to a Cisco console port locally. This is used when a remote network operator wishes to invoke Rommon Reboot on the Remote Cisco device.

(Please note, the Cisco device has to be powered down and back on again by a local person).

To send a break sequence, type B<CR>

OK: Available Ports

- 1 Cisco Console-01
- 2 Cisco Console-02
- 3 Cisco Console-03
- 4 Cisco Console-04
- 5 Cisco Console-05
- 6 Cisco Console-06

Select Port or <CR> alone to quit :

Choose port 1 to 6<CR> depending which port you wish to send the break signal to??

Once the break signal has been sent, you will see:

"Sending Break"

You will have been returned to the Pushkablu Setup Options main menu

(1) – Set Comms Options

This section is dealt with later in this document but covers the following subjects (Page 23):

- (1) - Set Inactivity Timeout
- (2) - Set Disconnect Character
- (3) - Set PB Flow Control
- (4) - Set Login Prompt Display
- (5) - Set Dialling Type
- (6) - Line Modulation Speeds
- (7) - Set Number of Dial In Rings

(3)- Set Port Names

You may wish to change the FF06-2P console port (1 to 6) names, so operators can identify the correct console device.

From the Main Menu , choose Pushkablu Setup Options, then

Choose **3** Set Port names.

(Example F<CR>, then 3<CR>)

You will be asked to choose a port number

Select Port 1 2 3 4 5 6 A1 B1 :

So if you wish to change console 1 to another name such as Cisco-2800-01

Type: 1<CR>

Current Port Label : Console

Change (y/n)?

Type: Y<CR>

Next you will be asked to input the console port name (Spaces are allowed) 1-32 Characters.

Enter Port Label (Up to 32 Characters) :<New Port Name><CR>

When you go back to the Main Menu, you should now see the Console port name has been changed.

(4) – Set System Time and Date

To Change the System Time and Date

From the Main Menu , choose Pushkablu Setup Options, then

Choose **4** Set System Time and Date

(Example F<CR>, then 4<CR>)

You will be given a prompt:

Current time is 01Jan1980 02:32:11

Change (y/n)?

Type: Y<CR>

You will receive another prompt:

Enter Date (dd/mm/yy):

The date is set DD/MM/YY, example: 31/12/08,

So Type: DD/MM/YY<CR>

Another prompt for the time will appear: Enter Time (hh:mm:ss):

The Time is set HH:MM:SS, example: 23:10:00

So Type: HH:MM:SS<CR>

You will then be sent back to the Pushkablu setup Options menu.

(5) – Set Comm Port Speeds

All of the console port (1 to 6) default speeds are 9,600bps. To change the console port speed.

From the Main menu, choose Pushkablu Setup Options,

Choose **5**- Set Comm Port speeds.

Example: F<CR>then 5<CR>

You will be asked to choose a console port:

Current Console Port Speeds:

1 Console	9600
2 Console	9600
3 Console	9600
4 Console	9600
5 Console	9600
6 Console	9600

Select Port or <CR> alone to quit :

To change the Console Port speed of Console 1

Type: 1<CR>

A New Menu will appear:

(1) - 9600

(2) - 19200

(3) - 38400

(4) - 57600

(5) - 115200

(X, <CR>) - Back to Previous Menu

Select Speed:

Now choose the speed you require, for example 2<CR> for 19200bps

Current Console Port Speeds:

1 Console	19200
2 Console	9600
3 Console	9600
4 Console	9600
5 Console	9600
6 Console	9600

Select Port or <CR> alone to quit :

Now you can see that Console 1 has changed to 19,200bps. Hit <CR> to Exit or choose 1-6 for another port speed.

(6) - Set Security Keys

This function is where you set up the security ID keys which work with the Pushkablue Secure Administrator and Other Pushkablue models: (FF02-1P, FF02-1PB, FF03, FF06, FF16, FF03-3P, FF06-2P FF06-2P),

PLEASE NOTE: IF YOU DO NOT INTEND TO USE THE PUSHKABLUE SECURE ADMINISTRATOR OR DIAL OUT USING A PUSHKABLUE DEVICE, THIS FUNCTION MUST BE LEFT DISABLED.

From the Pushkablue Setup Options Menu Type **6**<CR>
This line appears:

Admin Security Key is Currently Enabled
Change (y/n)? Type Y<CR> if you wish to disable Admin Security Keys or

<CR> if you wish to leave this feature enabled.)
It is recommended that you leave the Admin Security key enabled

Admin Security Key : AdminKeyDefault
Change (y/n)? Type Y<CR> if you wish to change the Admin Security Keys or <CR> if you do not)
normally left as default if you are not using Pushkablue Secure Administrator Software
If "Y"
This Line appears (*Please note: Any combination of Letters and numbers, Case Sensitive, No spaces*)
Enter Admin Security Key (10 to 20 Characters) :TypeLetTersaNdnumBers<CR>

PLEASE RECORD YOUR ADMIN KEY NOW
This line appears:
User Security Key : Disabled
Change (y/n)?Type Y<CR> if you wish to set up the security keys (or <CR> if you wish to leave this feature disabled.)
If "Y"
This line appears:

WARNING!! IF YOU CHOOSE THIS OPTION, YOU WILL NEED A PUSHKABLUE UNIT TO DIAL THIS DEVICE. THIS SECURE USER ID FEATURE WILL NOT ALLOW ANY CONVENTIONAL MODEM TO CONNECT TO IT. IF YOU DO NOT HAVE A CALLING PUSHKABLUE UNIT OR YOU ARE IN DOUBT CHOOSE "NO".
Confirm (y/n)?
Type: Y<CR> if you are happy to proceed or:

N<CR> if you do not wish to enable the User security key.
We will assume you have chosen yes.
Enter User Security Key (10 to 20 Characters) :Type LetTersaNdnumBers<CR>
(*Please note: Any combination of Letters and numbers, Case Sensitive, No spaces*)

Once you have entered the key a new line appears

Auto insert ID Key on Dial Out is Currently Disabled
Change (y/n)?

This feature enters the Secure User ID Key automatically on User dial out (Default: disabled)

If you wish to enable this feature Type: Y<CR> if not Type N<CR> or just hit <CR>

If you wish to disable this feature, follow the same procedure.

This takes you back to the Pushkablue Setup Options Menu.

(7) – Set Banner

You can enable a banner which will appear with the Login Prompt.

This Banner is to show unauthorised users that a prosecution will be invoked if unauthorised access is attempted.

To enable a banner, from the main menu, choose Pushkablu Setup Options,
Choose **7** Set Banner.

(Example: F<CR>, then 7<CR>)

You will be given a prompt:

Banner is Currently Disabled

Change (y/n)?

Type: Y<CR>

Another prompt will appear:

Enter Banner (Up to 254 Characters) <ESC> to end :

Type banner and press <ESC>Key when finished.

You can have up to 254 Characters and spaces are allowed and you can use <CR> to start another line.

Once finished, you will be taken back to the Pushkablu Setup Options Menu.

Other Main Menu Features

(I) Type: I<CR>,

This will refresh the Main Menu and give you the software revision information at the top of the Main menu

(L) Type: L<CR>,

This terminates the dial up connection.

(V) Type V<CR>,

This shows historical and current user activities on ports and changes of configuration.

(F) Type: F<CR>,

This enables the Administrator to configure the FF06-2P, such as prompt names, port names and port speeds as mentioned on previous pages.
This section goes into more detail later in this document on page [16](#)

(M) Type: M<CR>,

This takes you to the Manage User section covered later in this document on page [25](#)

Changing Admin 1 Name and Passwords

There are 3 ways to change the Default Admin user name and passwords

- 1) Using the (M) Manage Users option at the Main menu ([This page](#))
- 2) Send a text file from the Main Menu with abbreviated commands Page [11](#)
- 3) Using the Pushkablu Administrator windows software program Page [22](#)

Using the (M) Manage User Option at the Main Menu

At the Main menu choose (M)<CR>

A new menu will appear,

Choose Option 4<CR>

You will be asked: Change the Admin Login Name (y/n)?

Choose Y<CR>

Enter Name (1 to 16 Characters) : *enter new admin name here* <CR>

You will be asked if you wish to change the Administrator Password:

Change the Password (y/n)?

Choose Y<CR>

Enter First Password (<CR> to disable, or 8 to 16 Characters): enter *new admin password here*<CR>

Confirm First Password: *re enter new admin password here* <CR>

Enter Second Password (<CR> to disable, or 8 to 16 Characters) : enter new admin second password here<CR>

Please note: if you do not want a second password hit <CR>

Confirm Second Password: *re enter new admin second password here*<CR>

Enter Dial Back Number (<CR> alone for none) : *enter dial back number for administrator here*<CR>

Please note: if you do not want a dial back number hit <CR>

Once this has been achieved, you will be sent back to the Managed User menu

PLEASE MAKE SURE YOU RECORD THE CHANGED ADMIN NAME AND PASSWORDS NOW


IF YOU FORGET THE ADMIN USER NAMES AND PASSWORDS, PLEASE REFER TO THE LAST PAGE ON THIS DOCUMENT FOR FACTORY RESET PROCEDURES.

Pushkablu Secure Administrator Software

The 3rd Option for changing the Administrator name and all security details is the use of the Pushkablu Secure Administrator Windows software which is supplied free of charge on CD or via the web site: [www. Pushkablu.co.uk](http://www.Pushkablu.co.uk)



Main welcome screen



Manage Administrator and Users security window

Manage Banner and User ID key Window

For further details on how to operate the Pushkablu secure Administrator, please access the software and user guide from the CD or web site: www.pushkablu.co.uk

Set Comms Options

This section explains the operations of the various Comms options available.

From the Main Menu, choose F<CR> (Pushkablu set Up Options)

(B) - Send Break Signal
(1) - Set Comms Options
(2) - Set Prompt
(3) - Set Port Names
(4) - Set System Time & Date
(5) - Set Comm Port Speeds
(6) - Set Security Keys
(7) - Set Banner
(X, <CR>) - Back to Previous Menu
Ok :

Then Choose 1<CR> Set Comms Options

This menu will appear:

(1) - Set Inactivity Timeout
(2) - Set Disconnect Character
(3) - PB Flow Control Enable/Disable
(4) - Set Login Prompt Display
(5) - Set Dialing Type
(6) - Line Modulation Speeds
(7) - Set Number of Dial In Rings
(8) - Set FF06S Slave Configuration
(X, <CR>) - Back to Previous Menu
Ok :

We will explain each option from the top down.

1) Set Inactivity Timeout

This feature will disconnect the modem from a call when it does not see active data after the given time set.

To set Inactivity timeout (Default 5 minutes)

Type 1<CR>

Current inactivity Timeout: 5

Change (Y/N)? will appear.

Type<Y><CR> if you wish to change the time in minutes (1-99 or 0 for disable)

or <CR> if you do not wish to change it.

(2) - Set Disconnect Character

This feature enables you to change the serial port (1-3) disconnect character. So when you have a port connection and you wish to disconnect and go back to the Main Pushkablu menu, Type the character 3 times in a row.

The factory default is CTRL-X. (Hold the <CTRL> key down and type X 3 times).

To set Disconnect Character (Default CTRL-X)

Type 2<CR>

Current disconnect character: Ctrl-x

Change (Y/N)?

Type Y<CR>

Enter Disconnect character: X<CR> (X = the disconnect character you have chosen, Case sensitive)

You will then be returned to the Comms options menu.

It is important to remember that the disconnect character you have chosen will be displayed once you connect to a port.

You must type that character 3 times to achieve disconnect from that port.

3) Set PB Flow Control (default: Enabled)

The PB flow control feature is enabled for serial devices that do not have Flow control (RTS/CTS) such as Cisco Console Ports

PB Flow control factory default is enabled. To disable PB Flow Control type Y<CR>
You will returned to the Comms options menu.

To enable PB Flow control follows the same steps as above.

4) Set Login prompt display

This function gives you the option to display or not display the initial login prompt when connecting to Pushkablu, The Factory default is set to enabled.

To enable or disable Login prompt

Type 4<CR>

Login prompt currently: enabled

Disable Login prompt (Y/N)? Type Y<CR> if you wish the Login prompt not to appear in the menus screen or <CR> to re-enable the Login prompt follow the same steps as above.

(5) - Set Dialling Type

From the Comms Options Menu, Choose 5<CR>

This will allow you to change from Tone Dialling to Pulse Dialling or Pulse Dialling to Tone Dialling

Current Dialling Type is: Tone

Change Dialling Type to Pulse (y/n)? Type: Y if you wish to change to pulse or Type: N<CR> or <CR> if you wish to leave unchanged.

(6) - Line Modulation Speeds

This section allows you to select the minimum-maximum line speed session of the modems. This feature is very useful when there is a poor quality line. By choosing the lower connect speeds, increases the connection rate between the Pushkablu's or other calling modem.

From the Comms Options Menu, Choose 6<CR>

A menu will appear

(1) - V34 (33600bps - 2400bps)

(2) - V32B (14400bps - 4800bps)

(3) - V22B (2400bps - 1200bps)

(4) - Show Current Line Speed Setting

(X, <CR>) - Back to Previous Menu

Choose one of the options (1 to 3)<CR> to change the connect speed range or; Choose 4<CR> to see what the current connect speed range is.

(7) - Set Number of Dial In Rings

This function enables you to set the number of times the telephone line rings before the Pushkablu will answer.

(1-9 rings) default is 2 rings

Choose 7<CR>

This line appears:

Current Dial In Rings : 2

Change (y/n)? Choose Y<CR> if you wish to change the number of rings (1-9) or N<CR> or <CR> to exit this function

Pushkablu Manage Users

Manage user via Menu Commands

This section covers how to manage users, their passwords and their Port Assignments, using the Menu Commands.

This is where you manage the user names and passwords for access to Pushkablu's serial and power ports.

To Manage Users from the Main Menu Type **M**<CR>

A Menu will appear

(1) Add a User:

Type **1**<CR>

This Line will appear:

Enter User Name (1 to 16 Characters) :Type<UserName><CR>(Case Sensitive)

This Line will appear:

Enter First Password (<CR> to disable, or 8 to 16 Characters) :

Type<PassWoRd><CR>(Case Sensitive minimum 8 characters)

This Line appears:

Confirm First Password :Type<PassWoRd><CR> again

This Line appears:

Enter Second Password (<CR> to disable, or 8 to 16 Characters): Type<SecondPassWoRd><CR>

This Line appears:

Confirm Second Password: Type<SecondPassWoRd><CR> again

This Line appears:

Enter Dial Back Number (<CR> alone for none): Type<Dial Back Number>or<CR> for no dial back number.

This Line appears:

Enter Access List (<CR> alone to end) : 1 to 6 Type: <1 to 6 ><CR>

(Please note: A user can be allowed either 1 to 6 or All ports. Type the lowest number first the hit <CR>, for example, if a user is allowed access to port 1 and 2 only, then type<1><CR>, you will then be asked for another port as shown below)

This Line appears:

Next Port :(Either type the next port that is allowed or type<CR> to exit port allocation function)

Follow the above steps until you have allocated the ports you want this user to have access to.

(Please note: when the user access the Pushkablu. It will only show the ports available to that user).

A new Line will appear:

Dial Out Authority (y/n)?

This enables the particular user to have access to dial out functions on this Pushkablu.

If you wish this user to have dial out function type: **Y**<CR>, if No Type: **N**<CR>

Once you have completed the Users Passwords, Port access assignments, dial back and dial out authority options, you will be returned to the Manage User Menu.

(2) Delete User:

Type<The User name><CR>(Type the exact name, case sensitive)

This will return you to the Manage user Menu (The user name would have disappeared)

(3) Delete ALL Users:

Type **3**<CR>

This Line will appear

Delete ALL users (No undo)? Type **Y**<CR> (If you wish to delete all users) or <CR> (if you do not)

(5) Show User configuration:

Type 5<CR>

Shows the User number, User Name, Ports Assigned, Dial Back Number & dial Out Authority

Press <CR> to go back to the manage Users menu

Dial Out and Answer call function

The (D) Dial out and (N) aNswer call features provide better utilisation of dial lines and greater dial security functions.

The dial out and Answer Call functions enables network operations to dial out via the Cisco Aux port (Reverse telnet) or a direct PC serial Connection to the TERM port of the FF06-2P.

A Pushkablu can be used to dial either another Pushkablu device or any other modem device.

There are two specific Pushkablu dial out security functions that are used

1) The Dialling out Pushkablu will automatically broadcast the Secure User ID Key (10 to 20 Digits) to the receiving Pushkablu.

2) Enables the network operator to accept a call back from a remote dial back Pushkablu or modem device.

How to make a dial out call (Via Term Port)

This instruction assumes you have logged onto the Pushkablu device via the TCP/IP Network.

From the main Menu Type: D<CR>

This line will appear:

Is there an ID key (y/n)?

If the Remote Pushkablu device has its Secure User ID Key enabled, type: Y<CR>

If the Remote Pushkablu device does **NOT** have a Secure User ID Key enabled or you are dialling another type of Modem device type: N<CR> or <CR> (Please skip until you see, Enter Number to Dial (5-16 digits:))

If "Y" the next line will appear:

Enter Security Key :<Enter the 10-20 Digit ID key that is configured in the Remote Pushkablu Device><CR>

This next line will appear:

Enter Number to Dial (5 - 16 digits) :< enter the telephone number of the remote Pushkablu device><CR>

(Please note: if you are using a telephone line that needs a 9 or 8 to get a dial line out add a comma (,) after the 9 or 8 to enable the Pushkablu device to pause before dialling the telephone number)

You will see: Dialling... (Please wait up to 1 minute for connection to remote end)

If the Secure user ID Key is incorrect or the Pushkablu does not have its Secure ID Key enabled you will see: ID key is incorrect.

If the Secure User ID key is correct you will see:

Connected (Press (Numpad) +++ to Disconnect call)

Login :< this is where you insert your user name and passwords to log on>

How to Disconnect the Call

There are two ways to disconnect the call

- 1) At the main menu of the remote FastFix type: L<CR> for Logout
- 2) Type 3 + (plus) signs (Keypad) quickly (example: **+++**) (Can be used with FastFix devices or any other modem device)

(N) aNswer Call

The (N) aNswer Call feature enables network operations to receive a call from a dial back modem. The example shown is from a remote Pushkablu device unit that has a user set up called Dialback001.

When you have connected to the remote Pushkablu device and you have successfully entered your dial back user account and password(s) the remote Pushkablu device will disconnect displaying the following message:

Will Dial Back in 30 Seconds...
Call Disconnected by Remote End

The dialling FastFix will return to the main menu

Type: N<CR>
This line will appear:
Waiting for connection (<ESC> to abort).

(As shown, if you wish to abort the answer call function, press Esc key)

Please wait for the remote FastFix to start its dial procedure (Normally 20-40 seconds)

You will after such time see:

Call coming in....

It takes approximately 10-15 seconds for the internal Pushkablu modems to synchronise.

Once this has been achieved, you will see:

Connected (Press +++ (keypad) to Disconnect call)
Login:

Login the same way you did before, in this case: Dialback001


RJ45 Serial Port Pin Outs & Standard Cable specification

The TERM port and the Console port TX and RX pin outs are identical, however, the TERM ports also supports DSR, DTR Signals. The Console Port supports ONLY TX, RX and GND.

The Console port Pins 1 to 8 and pins 2 to 7 are looped back, these pins (normally associated with signals RTS/CTS and DSR/DTR Signals).


The TERM port pins 1 to 8 are also loped back (Normally associated with RTS-CTS Signals).

Please refer to the pin out Matrix below for the pin outs required for your specific device attachment, or alternatively please refer to the following pages in this document for standard cable and adapter pin outs



Straight RJ45 to RJ45 (Patch Lead)


To Connect Pushkablue Console ports to Any Cisco, Checkpoint, Fortigate, Juniper, Nokia RJ45 Console Port



Part No:FF-DB9F


To Connect Pushkablue Console port to Any 9 Way DB Male (DTE) connection

Pushkablue to PC Comm Port Adapter




Part No:FF-MCAFEE

to Connect Pushkablue Console port to Any 9 Way DB Male (DTE) connection
Pushkablue to McAfee Network Appliances Comm ports



Signal	Pin	Color	Pin	Signal
	8	Blue	7	RTS
	7	Orange	4	DTR
Txd	6	Black	3	Txd
GND	5	Red	5	GND
GND	4	Not Connected		
Rxd	3	Yellow	2	Rxd
	2	Brown	6	DSR
	1	White	8	CTS

Rear View of Pushkablue to PC Comm Port Adapter 9 Way D Female (Part No: FF-DB9F)



Pushkablue Factory Default Reset

If You forget the Admin names and passwords, or you need to reset the FF06-2P back to Factory Reset, take a paper clip or pen and insert into the PWD Hole on the rear panel, as shown in the diagram (Right).

You will feel a button behind the rear panel, press slowly and you will feel the button push in.

Hold for 8 seconds, while the FF06-2P is powered up. This will make the FF06-2P **revert** to Factory default.



PWD Button (Rear of panel)

Spare 10 Amp Fuse


The FF06-2P uses an Anti-Surge Ceramic 10Amp fuse. (T10AH 250V)

This can be located in the fuse draw of the IEC C14 Power inlet as shown in the diagram (Right).

A spare fuse is also supplied, if required.

If further fuses are needed, please contact Pushkablue Data Communications Ltd for advice.

Warning: DO NOT use any other fuse other than the fuse described.



Fuse: Cooper Bussman 10 Amp Anti-Surge Ceramic RS Componets part No: 537-1060 (www.rswww.co.uk)

Multitech Internal V34 Globally Approved Modem (Part No: MT5600SMI)

The FF06-2P uses the Multitech MT5600SMI Internal V34 modem. Please see certificate below.



Declaration of Conformity

Application of Council Directive(s): 2006/95/EC, 2004/108/EC, 93/68/EEC, 1999/5/EC

Standard(s) to which conformity is declared:
EN60950-1:2001, EN55022:1998+A1:2000+A2:2003, EN55024:1998+A1:2001, TBR21:1998

Manufacturer's Name: Multi-Tech Systems, Inc.

Manufacturer's Address: 2205 Woodale Drive
Mounds View, Minnesota 55112
USA

European Representative: Multi-Tech Computers (U.K.) Ltd.
Attention: Mr. Adrian Girling
Unit 1, Thames Court
2 Richfield Avenue
Reading, Berkshire RG1 8EQ
United Kingdom

Type of Equipment: Analog Socket Modem

Model Number: MT5600SMI


Serial Number: 0000001 -

Year in which CE mark was first affixed: 2001

I, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s), and Standard(s).

Place: Mounds View, MN
USA

Date: August 27, 2009


(Signature)

Terry Boe
(Full Name)

Engineering Manager-Certifications
(Position)

Multi-Tech Systems, Inc. • 2205 Woodale Drive • Mounds View, Minnesota 55112 U.S.A.
(763) 785-3500 or (800) 328-9717 • Fax: (763) 785-9874 • www.multitech.com